



**Smart Safe
Catalogue No. S 2 E**

OPERATING INSTRUCTIONS





OPERATING INSTRUCTIONS FOR SAFE & ELECTRONIC CONTROL PANEL

IMPORTANT:

- Please keep your keys in a secure place, but **not** in the safe.
- Keep your personal code secure.
- Do not use personal data (eg: birthdays, telephone numbers etc).

HOW TO OPEN THE SAFE WITH THE KEY:

- Carefully remove the cover plate that is located next to the keypad.
- Insert the key and turn it anti-clockwise until it stops. Then turn the knob clockwise and open the door.

HOW TO INSTALL THE BATTERIES:

- Remove the plastic cover from the box located on the inside of the safe door. Insert 4 x AA Batteries, 1.5 V (Alkaline).

HOW TO PROGRAM YOUR PERSONAL CODE:

- Open the door.
- Press and release the **RED** button on the inner side of the door jamb.
- Enter your personal code. (3 - 6 digits).
- Press the **#** key to store your new code.

HOW TO OPEN THE SAFE USING THE KEYPAD:

- Enter your personal code (3 – 6 digits).
- Press the **#** key.
- After the melody you can open the door with the knob (turning clockwise).



HOW TO CLOSE THE SAFE:

- Close the door and turn the knob anti-clockwise.

BATTERY INDICATOR:

- The batteries should be replaced immediately if the **RED** light comes on.
- After having replaced the batteries the personal code must be re-programmed.

ALARM IN CASE OF WRONG CODE:

- After the third incorrect code the opening mechanism is blocked for 2 minutes.
- After this time has elapsed the safe can be opened with the correct code.

INSTALLATION:

- The safe can be installed by securing to a wall or the floor with the masonry bolts provided.