



Combi-Line Safe

PROTECTION



**Tested and certified
protection against
burglary and fire**



www.burgsecurity.com.au

Combi-Line Safes

CL 10 - CL 40 Safety cabinets "Combi-Line"

SECURITY LEVEL S 2

FIRE RESISTANCE GRADE LFS 30 P

- The new BURG-WÄCHTER safety cabinets with certification. For the safe storage of documents, cash, jewellery, arms or ammunition, coins and valuables.
- Security Level S 2 according to DIN EN 14450
- Security Level B according to VDMA 24992, May 1995
- Fire Resistance LFS 30 P according to prEN 15659 – 30 minutes fire protection for paper
- Fire-protective material according to DIN 4102
- Composite insulation in front of the door leaf as heat protection for the lock and bolts



- Tested and certified protection against burglary and fire
- Double-walled construction
- Internal hinge
- Lateral locking through strong round bolts of 25 mm Ø plus sliding bolt on the top
- All-over gripping rail on the hinge side
- Prepared for both wall and floor fixing
- Supplied with anchor bolts
- Colour: light grey
- Supplied with 1 shelf



CL 20 S



Version S

Security safe lock, VdS tested, ECB-S certified according to EN 1300 class A, 9 levers, 1,000,000 different combinations

Art.-No.	EAN	Exterior H x W x D	Interior H x W x D	Door H x W	Weight	Volume
	40 03482...	mm	mm	Opening mm	kg	l
CL 10 S	33400 3	320 x 435 x 380	205 x 320 x 232	205 x 265	44	15
CL 20 S	33420 1	360 x 495 x 445	245 x 380 x 297	245 x 325	55	27
CL 40 S	33440 9	560 x 495 x 445	445 x 380 x 297	445 x 325	77	50



CL 20 E



Version E

Electronic combination lock 'SecuTronic', VdS tested, ECB-S certified according to EN 1300 class B, 1,000,000 different combinations possible, incl. 3 batteries, type Micro LR 03 AAA.

Art.-No.	EAN	Exterior H x W x D	Interior H x W x D	Door H x W	Weight	Volume
	40 03482...	mm	mm	Opening mm	kg	l
CL 10 E	33410 2	320 x 435 x 380	205 x 320 x 232	205 x 265	44	15
CL 20 E	33430 0	360 x 495 x 445	245 x 380 x 297	245 x 325	55	27
CL 40 E	33450 8	560 x 495 x 445	445 x 380 x 297	445 x 325	77	50



Technical Advancement

Sliding bolt on the top provides additional protection against attack.

Safety cabinets Combi-Line CL 10 - CL 40



Subject to errors and changes. Minor variations of sizes and weight depend on production characteristics.

This brochure and other product brochures can be easily downloaded from

www.burgsecurity.com.au



Available From:



SIEPER & Co. Pty Ltd
Wholesale Distributors
Ph: (02) 9352 0600 | www.sieper.com.au