

**TSE 3003**



Made in Germany  
[www.burg-waechter.de](http://www.burg-waechter.de)

# Select Mode SecuTronic



## STSE / SecuTronic – Select Mode



### Lite Mode → Professional Mode :

Press the ON/Enter key.  
Press the function key.  
Press key 2 twice (menu option [Professional Mode]).  
Press the ON/Enter key.  
Enter your opening code.  
Enter your 4-digit code 3195.  
Press the ON/Enter key.  
To switch to Professional mode, confirm the setting again with the ON/Enter key.

### Professional Mode → Lite Mode :

Press the ON/Enter key.  
Press the function key.  
Select the menu option [Administrator] using keys 1 and 2.  
Press the ON/Enter key.  
Select the menu option [Lite Mode] using keys 1 and 2.  
Enter your valid administrator code.  
Enter the 4-digit code 7293.  
Press the ON/Enter key.  
To switch to Lite-Mode, confirm the setting again with the ON/Enter key.

### **Important !**

All extended settings such as user, calendar, time switch ... are re-set (deleted !) when converting the locking system from Professional Mode to Lite Mode. The first 6 digits of the Administrator code are then the normal user code as only a 6-digit code can be programmed in Lite Mode.

The Professional Mode is not licensed as standard for some safe models. In this case, it can be enabled/activated by purchasing an Opt. Funct. Key (*Optional Function Key*).

See: "TSE\_SecuTronic\_Operating\_instructions\_Professional\_Mode.pdf"

- Sections:
- Display Serial numbers
  - Input Licence key



## **Burg-Wächter KG**

Altenhofer Weg 15  
D - 58300 Wetter  
Germany

[www.burg-waechter.de](http://www.burg-waechter.de)  
[info@burg-waechter.de](mailto:info@burg-waechter.de)

Omissions and changes reserved  
Irrtum und Änderungen vorbehalten  
Sous réserve de fautes d'erreurs et de modifications  
Errores y modificaciones reservadas  
Errori e cambiamenti riservati  
Fouten en wijzigingen voorbehouden

B/A Tr HSE-jwe 12/2005